

TR-064 Support – WANCommonInterfaceConfig

Supported by AVM

Author: AVM GmbH

Date: 2023-01-20

1. urn:WANIfConfig-com:serviceId:WANCommonInterfaceConfig1

For details please refer the TR-064 document at

<https://www.broadband-forum.org/technical/download/TR-064.pdf>

2. History

Date	Version	Changes
2012-02-13	10	Example values for WANAccessTypes. Spelling, format.
2015-11-20	11	Add action X_AVM-DE_GetOnlineMonitor
2016-08-05	12	Updated URL for TR-064 document
2017-08-24	13	Example values for X_AVM-DE_GetOnlineMonitor
2018-09-05	14	Added allowed values for parameter WANAccessType and PhysicalLinkStatus
2021-07-06	15	Added allowed value “unknown” for parameter WANAccessType Added action X_AVM-DE_GetActiveProvider Added parameter X_AVM-DE_Provider
2021-09-22	16	Added parameter X_AVM-DE_DownStreamCurrentUtilization, X_AVM-DE_UpstreamCurrentUtilization, X_AVM-DE_DownstreamCurrentMaxSpeed, X_AVM-DE_UpstreamCurrentMaxSpeed for GetCommonLinkProperties
2022-02-15	17	Added required rights for actions
2022-02-17	18	Added a table to describe state variable for action X_AVM-DE_GetOnlineMonitor
2022-10-17	19	Added allowed value for AccessType
2023-01-20	20	Added description for actions GetTotalBytesSent, GetTotalBytesReceived, GetTotalPacketsSent and GetTotalPacketsReceived to clarify the counters

3. Action List

This chapter contains the supported actions of the service WAN common interface configuration which are listed incl. arguments.

4. GetCommonLinkProperties

Required rights: App, Phone, NAS or Homeauto

Argument name	Direction	Related state variable	Remarks
NewWANAccessType	out	WANAccessType	
NewLayer1UpstreamMaxBitRate	out	Layer1UpstreamMaxBitRate	
NewLayer1DownstreamMaxBitRate	out	Layer1DownstreamMaxBitRate	
NewPhysicalLinkStatus	out	PhysicalLinkStatus	
NewX_AVM-DE_DownstreamCurrentUtilization	out	X_AVM-DE_DownStreamCurrentUtilization	
NewX_AVM-DE_UpstreamCurrentUtilization	out	X_AVM-DE_UpstreamCurrentUtilization	
NewX_AVM-DE_DownstreamCurrentMaxSpeed	out	X_AVM-DE_DownstreamCurrentMaxSpeed	
NewX_AVM-DE_UpstreamCurrentMaxSpeed	out	X_AVM-DE_UpstreamCurrentMaxSpeed	

Table 1: Argument list of action GetCommonLinkProperties

5. GetTotalBytesSent

Returns the total number of bytes sent over all interfaces during their connection interval. If an interface establish a new connection, its counter gets reset to 0.

Argument name	Direction	Related state variable	Remarks
NewTotalBytesSent	out	TotalBytesSent	Needs IGD to work.

Table 2: Argument list of action GetTotalBytesSent

6. GetTotalBytesReceived

Returns the total number of bytes received over all interfaces during their connection interval. If an interface establish a new connection, its counter gets reset to 0.

Argument name	Direction	Related state variable	Remarks
NewTotalBytesReceived	out	TotalBytesReceived	Needs IGD to work.

Table 3: Argument list of action GetTotalBytesReceived

7. GetTotalPacketsSent

Returns the total number of packets sent over all interfaces during their connection interval. If an interface establish a new connection, its counter gets reset to 0.

Argument name	Direction	Related state variable	Remarks
NewTotalPacketsSent	out	TotalPacketsSent	Needs IGD to work.

Table 4: Argument list of action GetTotalPacketsSent

8. GetTotalPacketsReceived

Returns the total number of packets received over all interfaces during their connection interval. If an interface establish a new connection, its counter gets reset to 0.

Argument name	Direction	Related state variable	Remarks
NewTotalPacketsReceived	out	TotalPacketsReceived	Needs IGD to work.

Table 5: Argument list of action GetTotalPacketsReceived

9. X_AVM-DE_SetWANAccessType

Argument name	Direction	Related state variable	Remarks
NewAccessType	in	AccessType	

Table 6: Argument list of action X_AVM-DE_SetWANAccessType

10. X_AVM-DE_GetActiveProvider

Required rights : App or Phone

Argument name	Direction	Related state variable	Remarks
NewX_AVM-DE_Provider	out	X_AVM-DE_Provider	

Table 7: Argument list of action X_AVM-DE_GetActiveProvider

11. X_AVM-DE_GetOnlineMonitor

SyncGroupIndex can have a value from 0 .. TotalNumberSyncGroups-1 (from X_AVM-DE_GetOnlineMonitor).

Argument name	Direction	Related state variable	Remarks
NewSyncGroupIndex	in	SyncGroupIndex	
NewTotalNumberSyncGroups	out	TotalNumberSyncGroups	
NewSyncGroupName	out	SyncGroupName	
NewSyncGroupMode	out	SyncGroupMode	
Newmax_ds	out	max_ds	
Newmax_us	out	max_us	
Newds_current_bps	out	ds_current_bps	
Newmc_current_bps	out	mc_current_bps	
Newus_current_bps	out	us_current_bps	
Newprio_realtime_bps	out	prio_realtime_bps	
Newprio_high_bps	out	prio_high_bps	
Newprio_default_bps	out	prio_default_bps	
Newprio_low_bps	out	prio_low_bps	

Table 8: Argument list of action X_AVM-DE_GetOnlineMonitor

State variable	Description
SyncGroupIndex	0 .. TotalNumberSyncGroups-1
TotalNumberSyncGroups	Number of sync groups
SyncGroupName	Name of sync group
SyncGroupMode	Connection mod of sync group
max_ds	Max number of bytes per second in downstream direction
max_us	Max number of bytes per second in upstream direction
ds_current_bps	current number of bytes per second in downstream direction of multicast traffic
mc_current_bps	current number of bytes per second in downstream direction of home, guest and multicast traffic
us_current_bps	current number of bytes per second in upstream direction
prio_realtime_bps	current number of bytes per second in upstream direction of real-time home traffic
prio_high_bps	current number of bytes per second in upstream direction of important home traffic
prio_default_bps	current number of bytes per second in upstream direction of default home traffic
prio_low_bps	current number of bytes per second in upstream direction of background home traffic

Table 9: Description of state variables for action X_AVM-DE_GetOnlineMonitor

12. Service States Table

Variable name	Allowed values (* == default)	Data type
AccessType	DSL, Ethernet, X_AVM-DE_Fiber, X_AVM-DE_UMTS, X_AVM-DE_Cable, X_AVM-DE_LTE, unknown (*)	String
ds_current_bps		string
Layer1DownstreamMaxBitRate		ui4
max_us		ui4
mc_current_bps		string
PhysicalLinkStatus	Unavailable, Down, Initializing, Up	string
prio_default_bps		string
prio_high_bps		string
prio_low_bps		string
prio_realtime_bps		string
SyncGroupIndex	0 .. TotalNumberSyncGroups-1	ui4
SyncGroupName		string
TotalBytesReceived	0 if IGD is not used.	ui4
TotalBytesSent	0 if IGD is not used.	ui4
TotalNumberSyncGroups		ui4
TotalPacketsReceived	0 if IGD is not used.	ui4
TotalPacketsSent	0 if IGD is not used.	ui4
us_current_bps		string
WANAccessType	*unknown, DSL, Ethernet, X_AVM-DE_Fiber, X_AVM-DE_UMTS, X_AVM-DE_Cable, X_AVM-DE_LTE	string
max_us		ui4
X_AVM-DE_DownstreamCurrentMaxSpeed	Max value from list X_AVM-DE_DownstreamCurrentUtilization	ui4
X_AVM-DE_DownstreamCurrentUtilization	Comma separated list of bytes per second in downstream direction	string
X_AVM-DE_Provider		string
X_AVM-DE_UpstreamCurrentMaxSpeed	Max value from list X_AVM-DE_UpstreamCurrentUtilization	ui4
X_AVM-DE_UpstreamCurrentUtilization	Comma separated list of bytes per second in upstream direction	string

Table 10: Variable list